



FOR THE BOTTOM OF THE FABRIC TO BE ENTRENCHED.


5. FIX SELF-SUPPORTING GEOTEXTILE TO UPSLOPE SIDE OF POSTS

WITH WIRE TIES OR AS RECOMMENDED BY GEOTEXTILE MANUFACTURER.
6. JOIN SECTIONS OF FABRIC AT A SUPPORT POST WITH A 150MM OVERLAP.

4. BACKFILL TRENCH OVER BASE OF FABRIC.









J.D. EVANS and COMPANY

DESIGN AND BUILDING CONSULTANTS
74 RIVIERA AVENUE, AVALON BEACH, 2107
Phone 9918 9206 mobile 0418 976 596
www.ideco.com.au email info@ideco.com.au

PROJECT
PROPOSED ALTERATIONS/ADDITIONS
& SECONDARY DWELLING AT
No. 48 TATIARA CRESCENT
NORTH NARRABEEN N. S. W. 2101
DUNCAN & MURIEL_JOURNEE

DRAWN JDE CHECKED

DRAWN JDE SSUE

1818 - 9