

Note:

 Any discrepancies should be immediately referred to Serenescapes Landscape Designs
 All work to comply with B.C.A. Statutory Authorities and relevant Australian Standards. Dimensions recognised over scaling. All measurements are in millimetres

Copyright Serenescapes Landscape Designs 2021

Serenscapes Landscape Designs ABN 71 611 726 222

Belrose NSW 2085 Tel: 02 9986 2157 info@serenescapes.com.au www.serenescapes.com.au

Site Address: 105 Florida Road Palm Beach


Drawn by: Project Number: Eduardo Casellato 21805

TLA Member

Scale

10/08/2021 DA Issue Sheet Number: 1:100 @ A3 L-02 of 6





Note:

Denotes difference between Denotes unlerence bound coping & existing ground level

Note:

- Contractors to check and verify all dimensions and all levels on site prior to any works.

- Any discrepancies should be immediately reterred to Serenescapes Landscape Designs.

- All work to comply with B.C.A. Statutory Authorities and relevant Australian Standards.

- Dimensions recognised over scaling. All measurements are in millimetres.

- Copyright Serenescapes Landscape Designs 2021.



Serenscapes Landscape Designs

ABN 71 611 726 222

Tel: 02 9986 2157 info@serenescapes.com.au www.serenescapes.com.au

Client:	Judy Conley	Drawing Title: Setout Plan					
Site Address:	100 Florida Road	Drawn by: Eduardo Casellato	Project Number: 21805	Scale: 1:100 @ A3	Sheet Number: L-03 of 6		
	Palm Beach	TLA Member	21003	1.100 @ A3	L-03 01 6		




Checked:

BF

Date:


Issue:

10/08/2021 DA Issue



Sectional Elevation AA

Scale 1:100



Sectional Elevation BB

Scale 1:100

Contractors to check and verify all dimensions and all levels on site prior to any works.

Any discrepancies should be immediately referred to Serenescapes Landscape Designs
 All work to comply with B.C.A. Statutory Authorities and relevant Australian Standards.

- Dimensions recognised over scaling. All measurements are in millimetres. - Copyright Serenescapes Landscape Designs 2021.

serenescapes


Serenscapes Landscape Designs

ABN 71 611 726 222

Suite 54, 14 Narabang Way Belrose NSW 2085 Tel: 02 9986 2157 info@serenescapes.com.au www.serenescapes.com.au

Olient.	Judy Conley			
Site Address:	105 Florida Ro			
	Palm Beach			

	Drawing Title: Sectional Elevations			Rev:	Date:	Issue:	Checked:	
				_	Α	10/08/2021	DA Issue	BF
	Drawn bv:	Proiect Number:	Scale:	Sheet Number:				
oad	Eduardo Casellato	','''						
h	TLA Member	21805	1:100 @ A3	L-04 of 6				



# LANDSCAPE SPECIFICATION NOTES

#### SITE PREPARATION

Locate any underground and overground services & ensure no damage occurs. Levels on plan are nominal only & all dimensions to be checked on site prior to commencement. Final structural integrity of all items shall be the sole responsibility of landscape contractor.

# PROTECTION OF EXISTING TREES:

All tree protection is to be undertaken in accordance with the guidelines provided in AS4970-2009 Protection of trees on development sites.

Prior to construction, the builder shall erect tree protection fencing for each protected tree. Tree protection fencing setbacks are to be determined by multiplying the diameter at breast height by twelve (12). Fencing is to consist of Chain wire mesh panels at least 1.8m in height, anchored with concrete feet. Signage stating "Tree Protection Zone – No Access" is to be displayed on the fencing.

According to AS 4970-2009, activities excluded from the TPZ include but are not limited to;

- machine excavation including trenching
- excavation for silt fencing
- cultivation
- storage
- preparation of chemicals, including preparation of cement products
- parking of vehicles and plant and/or refuelling
- dumping of waste and/or wash down and cleaning of equipment
- soil level changes and/or placement of fill
- lighting of fires
- temporary or permanent installation of utilities and signs
- physical damage to the tree.

# REMOVAL OF EXISTING TREES

All trees to be removed shall be carried out by a qualified arborist and work shall conform to the provisions of AS4373-2007 Australian Standards for The Pruning of Amenity Trees.

# **ELIMINATE WEEDS**

Remove all existing weeds by hand, wiping or spraying with a glyphosate based herbicide. Weed control shall never be performed by mechanical cultivation or by scraping. Herbicide spraying is to be used to eliminate all existing weeds 30 days prior to planting.

# **EXCAVATION & SUB SOIL PREPARATION**

Excavate garden beds to the depth required and rip or scarify base & sides of pit to a minimum depth of 150mm.

#### SUB SOIL DRAINAGE

Install drainage layer where there is surface water runoff draining into garden bed areas & where the existing sub-soil has more than 50% clay composition & there is a risk of subsurface water ponding. Install perforated corrugated ag. line 75-100mm Dia. with geotextile filter sock & backfill to a minimum 200mm using free draining material, reclaimed/recycled where available. Direct flows at a minimum 0.5% fall to sw system. In areas isolated from stormwater system excavate & backfill an appropriate water dispersion pit.

# REUSE EXISTING TOPSOIL

Existing site topsoil should be salvaged & appropriately stockpiled where possible.

# IMPORTED TOPSOIL

Quality System: AS 4419 or as specified below.

Turf Areas: 'Turf Underlay' as supplied by, ANL p: 02 9450 1444 or approved alternative. Tree Pit and Shrub Planting: 'Premium Garden Mix' as supplied by, ANL p: 02 9450 1444 or approved

alternative.

#### PLANTING.

Health & Vigour: Supply plants with foliage size, texture & colour consistent with that shown in healthy specimens of the species. Crowns must contain no epicormic shoots or dieback.

Balance of Crown: Supply plants with max, variation in crown bulk on opposite sides of stem axis, +/- 20% All plants supplied should be consistent with the guidelines provided in AS2303-2015 Tree stock for landscape use.

### STAKING

Install 2 x 1800mm 40x40 hardwood timber stakes with hessian ties to all trees. Provide appropriate support considering exposure to prevailing winds. Stakes and hessian ties to be removed as soon as the tree is self supporting.

# ALUMINIUM GARDEN EDGING

Supply and install Link Edge 75mm as per Landscape Plan, Compact and level the base in the required area as indicated on Landscape Plan. Half hammer spikes into pre-punched holes (approx. 4 spikes every 3m length) starting from the first hole in the end of the Link Edge. Use spike washers supplied by manufacturer.Half hammer subsequent spikes in pivotal areas along the length. (Especially at points where a curve is required). Connect lengths together by using fish-plate connectors supplied by manufacturer. Check position of Link Edge is correct before hammering spikes firmly into ground.

### IRRIGATION SYSTEM

New dripline irrigation system to be installed with backflow preventer and with timers. Irrigation system to be designed and installed to local codes.

The entire irrigation system shall be fully automated and provide drip irrigation to all tree, shrub and ground cover zones. It is the Contractor's responsibility to verify water pressure available and determine all design-built parameters prior to any installation and sizing of irrigation components. Irrigation system to be connected to water tank to supplement water from mains.

#### MULCHING

Quality system: AS 4454

All planting area impacted by building works to receive 50-75mm of garden Mulch, Hort-Bark, ANL p: 02 9450 1444 or approved alternative. Keep mulch 100mm away from plant stem & form a well to stop excessive water runoff. Finish flush with adjacent surfaces.

#### TURFING

New turf- Sir Walter Soft Leafed Buffalo.

Excavate / grade all areas to be turfed to 120mm below finished levels. Ensure that all surface runoff is directed away from buildings. Ensure that no pooling or ponding will occur. Further rip the sub-grade to 150mm. Install 100mm of imported turf underlay. Rolls to be closely butted and laid in a brickwork pattern. Fill any small gaps with topsoil and water thoroughly.

# WATERING


Water in immediately after plant installation & allow for soil settlement. For the first 2 to 4 weeks after planting, the root zone & immediate surrounds must be kept moist. Continue watering until plants have established.


#### STEPPING STONES


Install each stepping stone on a 75mm thick mortar bed and space according to plan. Stones to finish flush with adjoining levels. Fill gaps with ground covers as specified.


# **RETAINING WALLS & PLANTER BOXES**

All retaining walls & planter boxes to be constructed to Engineer's details. Ensure all internal surfaces are waterproofed. Geotextile wrapped ag, drainage line backfilled with aggregate is to be installed behind all retaining walls & connected to stormwater in accordance with Sydney Water regulations. All planter boxes are to have Atlantis drainage cell (or approved alternative) installed & connected to stormwater in accordance with Sydney Water regulations.











Contractors to check and verify all dimensions and all levels on site prior to any works.

Any discrenancies should be immediately referred to Serenescanes Landscane Design

All work to comply with B.C.A. Statutory Authorities and relevant Australian Standard Dimensions recognised over scaling. All measurements are in millimetres Convright Serenescapes Landscape Designs 2021



Tel: 02 9986 2157 info@serenescapes Serenscapes Landscape Designs www.serenescapes ABN 71 611 726 222

ang Way	Clie
s.com.au s.com.au	Site

lient:		Drawing Title:				Rev:	Date:	Issue:	Checked:	
	Judy Conley	Landscape Specification & Details			Α	10/08/2021	DA Issue	BF		
ite Address:	105 Florida Road Palm Beach	Drawn by: Eduardo Casellato	Project Number: 21805	Scale: 1:100 @ A3	Sheet Number: L-06 of 6					